

EN – Distributor Button

PRODUCT NAME	Distributor Button
PRODUCT ID	2582
PRODUCT PHOTO	

PRODUCT DETAILS	
Product specification	Coffee Distributor
Dimensions	Ø 53 mm
Material	Stainless steel
Intended type of food	Coffee
Status	Material intended for contact with food

INSTRUCTIONS FOR USE
1. Loosen the distributor handle slightly by turning it counterclockwise. Once loosened, you can adjust the lower bladed part. 2. Holding the distributor body, turn the part with the blades to adjust the depth to which the distributor enters the coffee – that is, how much the layer in the portafilter is leveled. Set the depth so that the distributor only levels the coffee, not compresses it. 3. Once you have set the depth, tighten the black handle by turning it clockwise. This

will secure the distributor and prevent it from moving during use.

4. Pour the ground coffee into the portafilter and tap it lightly to settle the coffee evenly.
5. Place the distributor on the full portafilter and turn it several times. 2-6 turns should suffice.
6. After distribution, tamp the coffee with a tamper and clean the distributor using a dry cloth.

MAINTENANCE AND CLEANING

- Clean the distributor with a dry, soft cloth after each use.
- For a more thorough cleaning, scrub it with a damp cloth and then allow to dry thoroughly.
- Do not use abrasive cleaning agents or coarse dishcloths to avoid damaging the surface.
- The distributor is not dishwasher safe.
- Store in a dry place away from direct sunlight and heat sources.

SAFETY WARNING

- Only use the distributor to spread ground coffee in the portafilter.
- Do not expose it to high temperatures, open flames, or hot surfaces.
- Do not use excessive force when adjusting the depth to avoid damaging the screw mechanism.
- Keep out of reach of children.
- Avoid use if the product is visibly damaged.